


SERIES 60 WaterMax Valve Cutaway




1. Home / Service

Service position 1 provides conditioned water for household use.




SERIES 60 WaterMax Valve Cutaway




2. Brine Refill 2

(Absolute brining, Mode 2 only)

Prefills brine cabinet with correct balance of water to dissolve required amount of salt for capacity used, less unused reserve capacity.




SERIES 60 WaterMax Valve Cutaway




3. Pause

Appliance is Still in service.
The Pause position holds 2 hours while salt dissolves to ensure proper brine concentration.




	Hard Water
	Soft Water
	Brine Water

SERIES 60 WaterMax Valve Cutaway




4. Backwash 1

Backwashes the media compartments to remove accumulated sediments.




SERIES 60 WaterMax Valve Cutaway




5. Brine / Rinse

Counter current regeneration forces brine upward through the resin from the bottom of the tank. The first 1/3 of this cycle is used for brine draw. The balance of the cycle (2/3) is used as a slow rinse to remove remaining brine solution.




SERIES 60 WaterMax Valve Cutaway



6. Backwash 2

Backwashes media compartments to remove any brine traces as the final cleaning step.



SERIES 60 WaterMax Valve Cutaway



Bypass

When the bypass is engaged, no water flow is available through the appliance.

